

INSTALLATION GUIDE

安裝說明書 / 安装说明书

Please visit www.gigabyte.com for more product information.

Warranty

Gigabyte provides limited product warranty. For the latest and current terms of the Limited Product Warranty, please visit <http://www.gigabyte.com/support-downloads/customer-service.aspx> .

WEEE Information

This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU. For more information, please contact the local authority or your retailer where you purchased the product.

符合中国《电器电子产品有害物质限制使用管理办法》标示
产品中有害物质的名称及含量



部件名称	有毒有害物质或元素					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
机箱组	X	○	○	○	○	○
面板组	X	○	○	○	○	○
I/O模块	X	○	○	○	○	○
风扇	X	○	○	○	○	○
安装套件	X	○	○	○	○	○
电源	X	○	○	○	○	○

本表格依据 SJ/T 11364 的规定编制。
○：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。
X：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。
但所有部件都符合欧盟 RoHS 要求。









Asia (Headquarters)
GIGA-BYTE TECHNOLOGY CO., LTD.
Address: No.6, Baoqiang Rd., Xindian Dist., New Taipei City 231
Tel: +886-2-8912-4000
<http://www.gigabyte.com>

China
GIGABYTE CHINA
Address: 24/F, HaiTong Securities Tower, No.689 Guangdong Road, Shanghai, China
Tel: +86-21-6340-0912


Europe
G.B.T. TECHNOLOGY TRADING GMBH Germany
Address: Bullenkoppel 16, 22047 Hamburg, Deutschland
Tel: +49-40-25 33 040

North America
G.B.T. INC. USA
Address: 17358 Railroad Street, City of Industry, CA91748 USA
Tel: +1-626-854-9338

FITTING PACK / 安裝套件 / 安装套件


Figure	Part's Name	Qty	Used For
	Screw A	8	PSU(4)/GPU(2)
	Screw B	8	HDD(2)
	Screw C	20	SSD(8)/MB(6)
	Standoff – 6.5mm	3	
	Nut setter	1	Standoff installation
	Cable Tie	5	Cable management
	Screw D	12	FAN(12)
	Grommet	1	PSU Shroud

CPU Height : 190mm / GPU Length : 410mm / PSU Length : 250mm




THE I/O CONNECTORS AND LIGHTING POWER

連接輸出接頭以及面板燈光電源 / 连接输出接口以及面板灯光电源




INSTALLATION / 安裝說明 / 安装说明

1. Remove both side panels / 先拆下兩邊側板 / 先拆下两边侧板




*Be careful when handling the tempered glass panel.
*拿取強化玻璃側板時請小心
*拿取強化玻璃側板时请小心

2. Install the motherboard / 安裝主機板 / 安装主板




*The quantity of standoff 6.5mm depends on motherboard's type.
*銅柱所需數量取決於主機板類型
*铜柱所需数量取决于主机板类型

3. Install the power supply / 安裝電源供應器 / 安装电源供应器




4. Install the add-on cards / 安裝顯示卡 / 安装显卡




5. Install the hard drive / 安裝硬碟 / 安装硬盘

5.1 For 3.5" cage / 3.5" 插槽 / 3.5" 插槽



5.2 For 2.5" cage / 2.5" 插槽 / 2.5" 插槽



6. Cooling System Support / 散熱系統支援 / 散热系统支持

